

# Battery Charger

## Battery Charger Monitor Model 9600 Pin Assignments

<u>Connector Style A Pin Number</u>	<u>Connector Style B Pin Number</u>	<u>Terminal Board</u>	<u>Function</u>	
1	10	TP2-1*	24 Vdc input positive	} 14 Awg
7	7	TP2-2	24 Vdc input negative	
10	1	TP1-4	12 Vdc output positive	
15	22	TP1-5	12 Vdc output negative	
4	4	TP2-5	Temperature sensor (black wire)	} 22 Awg
5	5		Temperature sensor ground-shield	
6	6	TP2-6	Temperature sensor (white wire)	
8	8	JP-1	Alarm reset	
9	9	JP-1	Alarm reset	
11	11	TP1-1	Alarm relay NO	
12	12	TP1-2	Alarm relay common	
13	13	TP1-3	Alarm relay NC	
14	14	TP2-4	Heater	} 18 Awg
16	16	TP2-3	Heater reserved	

\* 10-11 Circuit breaker to circuit breaker TP2-1

